


# EX70

V1.00 11/7/2013

Auxiliary Display for DL20

## Installation Guide



**The DL-20 MUST have Firmware version 2.06 or Higher to operate with the EX70.**

**Do NOT Connect 115V AC or 220V AC to this unit!**

## Introduction

The EX70 is an auxiliary Display Unit for the DL-20 Multi-Function Elevator Processor. The EX70 comes in two sizes.


Model No. **EX70-7** has a 7 Inch Display



Model No. **EX70-10** has a 10 inch Display

When connected to a DL-20, the EX70 supplies an exact duplicate of what is displayed on the DL-20's display. Only one EX70 can be used with each DL-20 unit.

## Installation Steps

Make sure that the DL-20 that you are connecting this unit to, has a firmware version of 2.06 or higher. If NOT, update the DL-20 first.





**Do NOT connect 115V AC to this unit!**