




5.8 GHz Call Waiting Caller ID Cordless Telephone User's Guide

25839



EQUIPMENT APPROVAL INFORMATION

Your telephone equipment is approved for connection to the Public Switched Telephone Network and is in compliance with parts 15 and 68, FCC Rules and Regulations and the Technical Requirements for Telephone Terminal Equipment published by ACTA.

1. Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the US number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

Model 25839
00003988 (Rev. 1 Dom E)
05-20
Printed in China

THOMSON
ATLINKS USA, Inc.
101 West 103rd Street
Indianapolis, IN 46290
© 2005 ATLINKS USA, Inc.
Trademark(s) ® Registered
Marca(s) Registrada(s)

Notes

- This equipment may not be used on coin service provided by the telephone company.
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.
- If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

2. Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

LICENSING

Licensed under US Patent 6,427,009

HEARING AID COMPATIBILITY (HAC)

This telephone system meets FCC standards for Hearing Aid Compatibility.

US NUMBER IS LOCATED ON THE CABINET BOTTOM
REN NUMBER IS LOCATED ON THE CABINET BOTTOM

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

THE LIGHTNING FLASH AND ARROW HEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT.

SEE MARKING ON BOTTOM / BACK OF PRODUCT

CAUTION: RISK OF ELECTRIC SHOCK. DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF IMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT.

INTRODUCTION

CAUTION: When using telephone equipment, there are basic safety instructions that should always be followed. Refer to the **IMPORTANT SAFETY INSTRUCTIONS** provided with this product and save them for future reference.

Your Call Waiting Caller ID phone stores and displays specific information, provided by your local telephone company, to subscribers of Caller ID or similar caller identification services.

Your Call Waiting Caller ID phone enables you to:


- Identify callers before you answer the phone.
- View the time and date of each incoming call.
- Record up to 40 Caller ID messages sequentially.
- Know who called while you were away.

To get the most from your new phone, we suggest that you take a few minutes right now to read through this user's guide.

IMPORTANT: In order to use all of the features of this unit, you must subscribe to either the standard Name/Number Caller ID Service or the phone, you must subscribe to Call Waiting Caller ID Service.

IMPORTANT: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

HANDSET AND BASE LAYOUT



TELEPHONE JACK REQUIREMENTS

To use this phone, you need an RJ11C type modular telephone jack, which might look like the one pictured here, installed in your home. If you don't have a modular jack, call your local phone company to find out how to get one installed.

CORDLESS PHONE BASICS

VOLUME

- Plug the AC power adaptor into the electrical outlet and the DC connector into the jack on the bottom of the base.
- Place the handset in the base cradle. The charge/in use indicator turns on, verifying the battery is charging.
- Allow the phone to charge for 12 hours prior to first use. If you don't properly charge the phone, battery performance is compromised.

MUTE

Use mute during a phone conversation to speak privately and off-line with a third party.

- Press the mute button. **MUTE** shows in the display. The party on the telephone will not hear you.
- When finished, press the talk/end/call back button or place the handset on the base cradle to hang up.

WALL MOUNTING

ANSWERING A CALL

Your cordless phone uses a digital security system to protect against false ringing, unauthorized access, and charges to your phone line.

When you place the handset in the base, the unit verifies its security code. After power outage or battery replacement, you should place the handset in the base for about 20 seconds to reset the code.

DIGITAL SECURITY SYSTEM

CAUTION: Use only the ATLINKS USA, Inc. 5-2677 (black) power adaptor that came with this unit. Using other power adaptors may damage the unit.

NOTE: The phone is tone dial only and does not support pulse dial mode.

MAKING A CALL

- Pick up the handset and press the talk/end/call back button. Wait for the dial tone. The call timer starts counting minutes and seconds in the display.
- Dial a telephone number.
- When finished, press the talk/end/call back button again or place the handset on the base cradle to hang up.

PRE-DIALING

- Make sure the phone is OFF (not in TALK mode).
- Dial a telephone number (the number you dial shows in the display).
- When finished, press the talk/end/call back button again or place the handset on the base cradle to hang up.

NOTE: If you make a mistake dialing the number, use the del/chan button to backspace and erase the wrong number, and enter the correct number.

INSTALLATION

- Slip the mounting holes (on the back of the base) over the wall plate posts, and slide the unit down into place. (Wall plate not included.)
- Place the handset on the base cradle.

SET UP

- There are four programmable menus available: Language, Area Code, Ringer Tone, and Default Setting.
- During programming, you may press the flash/prog button at any time to go to the next option. To exit the menu, keep the previous setting and return to the standby mode, press the *exit button.

NOTE: You may enter up to 32 pre-dial digits.

REDIAL

While the phone is ON (in TALK mode), press the redial button to redial the last number you dialed (up to 32 digits).

OR -
While the phone is OFF (in standby mode), press the redial button and then the talk/end/call back button to redial the last number.

DISPLAY LANGUAGE

- Press the flash/prog button until >1ENG 2FRA 3ESP shows in the display. "1ENG" is the default.
- Use the Caller ID/vol (- or +) button or the touch-tone pad on the handset to enter your selection.

FLASH
Use the flash/prog button to activate custom calling services such as call waiting, which are available through your local phone company.

TIP: Don't use the talk/end/call back button to activate custom calling services such as call waiting, or you'll hang up the phone.

INSTALLING THE PHONE

- Press the flash/prog button until AREA CODE --- shows in the display. "---" is the default.
- Use the touch-tone pad on the handset to enter your three digit area code.

LOCAL AREA CODE
While talking on the phone, it may be necessary for you to manually change the channel to improve reception and reduce noise or static on the line. Press and release the del/chan button to move to the next clear channel.

CHANNEL BUTTON
As calls are received and stored, the display is updated to let you know how many calls have been received.

REVIEWING CID RECORDS
NOTE: Check with your local phone company regarding name service availability.

- Make sure the phone is OFF (not in TALK mode).
- Press the mem button.

3. Press the desired memory location (0 through 9) or use Caller ID/vol (+ or -) to scroll to the desired memory location.

NOTE: If the memory location is occupied, the memory location number and its contents show in the display.

4. Press the mem button again. The display shows ENTER NAME.
- NOTE:** If you don't want to enter the name, skip step 5.

5. Use the touch-tone pad on the handset to enter the name (up to 15 characters) and press the mem button to save. More than one letter is stored in each of the number keys. For example, to enter the name Bill Smith, press the 2 key twice for the letter B. Press the 4 key 3 times for the letter I. Press the 5 key 3 times for the letter L. Wait for one second. Press the 5 key 3 times for the second letter L. Press the 1 key to insert a space between the L and the S. Press the 7 key 4 times for the letter S; press the 6 key once for the letter M; press the 4 key 3 times for the letter I; press the 8 key for the letter T; press the 4 key twice for the letter H.

6. Press the mem button to save the name. The display shows ENTERTEL NUMBER.

EXIT

Press the *exit button to cancel any command you initiated.

FINDING THE HANDSET
This feature helps locate a misplaced handset.

CAUTION: To reduce the risk of fire or personal injury, use only the battery 5-2459, which is compatible with this unit.

NOTE: You must connect the handset battery before use.

1. Make sure the phone is OFF (in standby mode).
2. Press the Caller ID/vol (- or +) button to scroll to the desired caller ID.
3. Press the mem button.

4. Press a number key (0 - 9) to store the number in that memory location. You will hear a confirmation tone.

NOTE: It is important that you format the caller ID records correctly before storing in memory. It is not possible to re-format caller ID records stored in memory.

RINGER SWITCH

The ringer switch is located on the side of the handset, it has two positions, On and Off.

NOTE: You may still page the handset when the ringer is off.

DEFAULT SETTING

1. Press the flash/prog button until DEFAULT > NO shows in the display. "NO" is the default.
2. Press the Caller ID/vol (- or +) button to scroll to the desired caller ID.
3. Press the mem button.

4. Press a number key (0 - 9) to store the number in that memory location. You will hear a confirmation tone.

NOTE: It is important that you format the caller ID records correctly before storing in memory. It is not possible to re-format caller ID records stored in memory.

RINGER TONE

Press the flash/prog button until RINGER TONE > 1 shows in the display. "1" is the default.

FINDING THE HANDSET

Press the page button on the base. The handset beeps continuously for about 2 minutes until you press the talk/end/call back button on the handset or the page button on the base.

NOTE: You must connect the handset battery before use.

1. Choose an area near an electrical outlet and a telephone wall jack (RJ11C), and place your cordless telephone on a level surface, such as a desktop or tabletop, or you may mount it on the wall.

2. Install the handset battery.

Press the page button on the base. The handset beeps continuously for about 2 minutes until you press the talk/end/call back button on the handset or the page button on the base.

3. Press flash/prog to save.

NOTE: You will hear a confirmation tone.

TRANSFERRING CALLER ID RECORDS IN MEMORY

1. Make sure the phone is OFF (in standby mode).

2. Press the Caller ID/vol (- or +) button to scroll to the desired caller ID.

3. Press the mem button.

4. Press a number key (0 - 9) to store the number in that memory location. You will hear a confirmation tone.

NOTE: It is important that you format the caller ID records correctly before storing in memory. It is not possible to re-format caller ID records stored in memory.

RINGER SWITCH

The ringer switch is located on the side of the handset, it has two positions, On and Off.

NOTE: It is important that you format the caller ID records correctly before storing in memory. It is not possible to re-format caller ID records stored in memory.

TO REPLACE AN OLD MEMORY With a NEW CID RECORD

1. Repeat steps 1 through 4 in Transferring Caller ID Records in the Memory. After you enter the memory location, **REPLACE MEMO?** shows in the display.

2. Press the mem button again, and the new CID record replaces the old memory in that location. You will hear a confirmation tone.

DELETING THE CURRENT CID RECORD

1. Make sure the phone is OFF (not in TALK mode).

2. Use the Caller ID/vol (- or +) button to scroll to the desired record.

3. Press del/chan. The display shows **DELETE CALL**

7. Use the touch-tone pad to enter the telephone number you want to store (up to 24 digits).

8. Press mem again to store the number. You will hear a confirmation tone.

NOTE: If you make a mistake press the del/chan button to backspace and erase the wrong character(s) or number(s).

CHANGING A STORED NUMBER

1. Repeat steps 1 through 7 in Storing a Name and Number in Memory.

2. Press the mem button, and **REPLACE MEMO?** shows in the display.

3. Press the mem button to store the number. You will hear a confirmation tone.

STORING A REDIAL NUMBER

1. Repeat steps 1 through 6 in Storing a Name and Number in Memory.

2. Press the redial button.

3. Press the mem button to store the number. You will hear a confirmation tone.

To replace an old number with a new redial number:

1. Repeat steps 1 through 6 in Storing a Name and Number in Memory.

2. Press the redial button.

3. Press the mem button, and **REPLACE MEMO?** shows in the display.

4. Press the mem button again to replace the old number with the new number. You will hear a confirmation tone.

NOTE: The stored redial number is limited to 24 digits or less.

DIALING A STORED NUMBER

1. Make sure the phone is **ON** by pressing the talk/end/call back button.

2. Press the mem button.

3. Press the memory location (0-9). The number dials automatically.

- OR -

1. Make sure the phone is **OFF** (not in TALK mode).

2. Press the mem button.

3. Use the touch-tone pad or the Caller ID/vol (- or +) button to scroll to the number you want to dial.

4. Press talk/end/call back. The number dials automatically.

INSERTING A PAUSE IN THE DIALING SEQUENCE OF A STORED NUMBER

If a pause is needed to wait for a dial or access tone, press the #pause button to insert a delay in dialing sequence of a stored number (for example, after you dial 9 for an outside line, or to wait for a computer access tone.) pause shows in the display as a **P**, and each pause counts as one digit in the dialing sequence.

REVIEWING AND DELETING STORED NUMBERS

1. To review stored numbers, press the mem button, and use the Caller ID/vol (- or +) button to scroll to the memory location, or press the corresponding number key for a desired memory location (0-9).

2. When the data shows in the display, press the del/chan button. The display shows **DELETE?**

3. Press del/chan again to delete the data. The display shows **DELETED**.

CHAIN DIALING FROM MEMORY

Use this feature to make calls which require a sequence of numbers, such as calling card calls to a frequently called long distance number. Each part of the sequence is dialed from memory. The following example shows you how to use chain dialing to make a call through a long distance service:

The Number For	Memory Location
Long distance access number	7
Authorization code	8
Frequently called long distance number	9

1. Make sure the phone is **ON** (in TALK mode).

2. Press mem and then press 7.



3. When you hear the access tone, press mem and then press 8.

4. At the next access tone, press mem and then 9.


TIP: Wait for the access tones before pressing the next memory button, or your call might not go through.

HEADSET AND BELT CLIP OPERATION

CONNECTING AN OPTIONAL HEADSET TO THE HANDSET



ATTACHING THE BELT CLIP



To attach the belt clip, insert the sides of the belt clip into the slots on each side of the handset. Snap the ends of the belt clip into place.

CHANGING THE BATTERY

Make sure the telephone is **OFF** (not in TALK mode) before you replace battery.

1. Remove the battery compartment door.


2. Disconnect the cord attached to the battery pack and remove the battery pack from the handset.

3. Insert the new battery pack and connect the cord to the jack inside the battery compartment.

4. Put the battery compartment door back on.

5. Place handset in the base to charge. **Allow the handset battery to properly charge (for 12 hours) prior to first use or when you install a new battery pack. If you do not properly charge the phone, battery performance will be compromised.**

CAUTION: To reduce the risk of fire or personal injury, use only the battery listed in the instruction book.



BATTERY SAFETY PRECAUTIONS

- Do not burn, disassemble, mutilate, or puncture. Like other batteries of this type, toxic materials could be released which can cause injury.
- To reduce the risk of fire or personal injury, use only the battery listed in the User's Guide.
- Keep batteries out of the reach of children.
- Remove batteries if storing over 30 days.

DISPLAY MESSAGES

The following messages show the status of the phone or help you set up and use your phone.

INCOMPLETE DATA Caller information is interrupted during transmission or the phone line is excessively noisy.

ENTER NAME Prompt telling you to enter a name for one of the 10 memory locations.

DELETE ALL? Prompt asking if you want to erase all Caller ID records.

DELETE CALL ID? Prompt asking if you want to erase the current Caller ID record that is shown on the display.

DELETED Prompt confirming a CID record is erased.

DELETE? Prompt asking if you want to erase one of the 10 numbers stored in the phone's outgoing memory.

END OF LIST Indicates there is no additional information in the Caller ID memory log.

NEW Indicates call or calls have not been reviewed.

UNKNOWN NAME/CALLER/NUMBER The incoming call is from an area not serviced by Caller ID or caller information is not sent.

PAGING Someone is paging the handset from the base.

BLOCKED CALL Caller information is blocked from transmission.

BLOCKED NAME/NUMBER Caller name and number is blocked from transmission.

REPT Repeat call message. Indicates that a new call from the same number was received more than once.

NO DATA No Caller ID information was received.

EMPTY Indicates a memory location is vacant.

NO CALLS Indicates no calls have been received.

MESSAGE WAITING Indicates a message is available.

LOW BATTERY Indicates the handset battery is low and needs charging.

UNABLE TO DIAL Indicates the CID or memory contents cannot be dialed.

UNABLE TO STORE Indicates the CID or memory contents cannot be stored.

PRESS TALK KEY Indicates the CID number is a Directory Dial Number (DDN) and cannot be formatted.

HANDSET SOUND SIGNALS

TROUBLESHOOTING TIPS

CALLER ID SOLUTIONS

No display

- Fully charge (for 12 hours) or replace the battery.
- If you are using AC (electrical) power, make sure that the unit is connected to a non-switched electrical outlet. Unplug the AC power adaptor from the unit and plug it back in.

Keep batteries out of the reach of children.

Remove batteries if storing over 30 days.

To see Caller ID information in your display, you must be subscribed to Caller ID service through your local telephone company.

Caller ID incomplete

- The unit displays this message if it detects anything other data message than valid Caller ID information during the silent period after the first ring. This message indicates the presence of noise on the line.

Atmospheric conditions, such as strong storms.

Base is installed in the basement or lower floor of the house.

Base is plugged into an AC outlet with other electronic devices.

Baby monitor is using the same frequency.

Handset battery is low.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).

• Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.

• Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

Handset does not ring

• Make sure the RINGER switch on the handset is turned to ON.

• You may have too many extension phones on your line. Try unplugging some phones.

• See solutions for "No dial tone."

Charge/in use indicator on the base flashes

- Provided your phone company offers voice messaging service and you subscribe to it, the charge/in use indicator on the base flashes when the phone is not in use to indicate there is a message waiting.

It stops flashing after the message has been reviewed.

You experience static, noise, or fading in and out

• Change channels

• The handset maybe out of range. Move closer to the base.

• Relocate the base.

• Charge the battery.

• Make sure base is not plugged into an electrical outlet with another household appliance.

Unit beeps

• Place handset in base cradle for 20 seconds to reset the security code. If that doesn't work, charge the battery for 12 hours.

• See solutions for "No dial tone."

• Replace the battery.

Memory dialing

• Make sure you correctly program the memory location keys.

• Make sure you follow the proper dialing sequence.

• You must reprogram numbers into memory after a power outage or battery replacement?

Purchase date

Name of store

INTERFERENCE INFORMATION

Out of range

- Move closer to the base.

Reset the battery. Unplug the battery and plug it in again after five seconds.

For how long after your purchase:

• One year, from date of purchase.

(The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.)

What we will do:

- Provide you with a new or, at our option, a refurbished unit. The exchange unit is under warranty for the remainder of the original product's warranty period.

How you get service:

- Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the original carton and packing materials.

• "Proof of purchase in the form of a bill of sale or receipted invoice which is evidence that the product is within the warranty period, must be presented to obtain warranty service." For rental firms, proof of first rental is also required. Also print your name and address and a description of the defect. Send via standard UPS or its equivalent to:

ATLINKS USA, Inc.

c/o Thomson

11721 B Alameda Ave.

Socorro, Texas 79927

- Pay any charges billed to you by the Exchange Center for service not covered by the warranty.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications

Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

What your warranty does not cover:

- Customer instruction. (Your Owner's Manual provides information regarding operating instructions and user controls. Any additional information, should